MATWORKS
PROTECT EVERY STEP

Website: www.thematworks.com
Phone: 833.628.9757
Mail: orders@thematworks.com

Installation and Maintenance

SURE STRIDE MATTING

RECOMMENDED APPLICATION AREA:


Produce Section


Organic Section


Ice Machine


Soda Station


Coffee Dispense Area


Bottom of Stairs


Drinking Fountain


Honey Station


Floral Area


Water Refill Station

TO INSTALL SURE STRIDE MATTING:

- The floor must be clean and dry.
- Measure to your desired length and place the cutting board beneath the mat at the location of the cut. Use the safety knife to cut the mat.
- Position the mat in the desired location, then use the cutting board to press and smooth the mat into place to ensure adhesion. Work from center to the edges to remove any air bubbles.
- Cut the corners at a 45-degree angle using the cutting guides on the cutting board.
- Click here to watch the video.

CLEANING INSTRUCTIONS:

- Do not pick up your Sure Stride mat to clean the floor underneath until you are ready to replace the mat.
- Sure Stride mats can be left in place during regular cleaning. Floor scrubbers, vacuums, brooms, and mops will pass right over without damaging the surface of the mat. Please use low settings for water and pressure. Tougher stains may be pretreated with standard carpet cleaning products and agitated with a brush to loosen the soil.
- Sure Stride mats are designed to dry quickly, however, standard fans or floor blowers can be used to speed the drying time. For extremely wet conditions, use a wet vac or extractor to remove water.
- Sure Stride mats are designed to last up to 4 months under normal use. Mats should be replaced if they show signs of wear, damage, or a weakened bond to the floor, and they should always be changed out within 4 months regardless of wear.